

Motorised Roman Blind

Complete Programming

Supplied by
SG-S | Silent Gliss Spares
Silent Gliss Systems
www.sg-s.co.uk email:sales@sg-s.co.uk tel:0330 1272002

how to...


Reset & Program your motor



See our instructional video here on how to program your motor.

1. Putting your blind into programming mode...

Only connect the motor that should be programmed to power. When programming a multi channel control, choose channel first.



Press and hold button on the motor. Motor jogs 3 times... first after 2 sec, after 7 sec and after 12 sec. → OK

When using a multi channel handset please ensure you select the appropriate channel before continuing to program your blind. This step is not applicable to single channel remotes.

Press the circle button until the light indicator is lit for your chosen channel



Press and hold UP and DOWN until the motor jogs

2. Check the motor direction...



or



if OK, skip to step 4

if **NOT** OK, follow step 3

3. If you need to change the motor direction...



Press and hold MY until the motor jogs

4. Place the blind in the desired UP position...



Press and hold UP until the blind is at the desired top position

5. Set the DOWN position...



Press then release MY and DOWN together

Blind goes down, must press stop before the blinds reaches the bottom

Stop near desired down position

Adjust to desired down position

6. Set the UP position...



Press then release MY and UP together

The motor moves upwards and stops at the UP position

7. Confirm end limit setting...



Press and hold MY until the motor jogs

8. Record an RTS transmitter...



Press and release the programming button on the back of the remote... motor jogs to confirm limits are locked and setup is complete

how to...

test if your blind is in roman mode

Raise your blind to the top, press and hold the down button.

If your blind doesn't reach the bottom then follow instructions below to set the blind into roman mode.

1.



Place the blind half way down

2.



5 sec.



Press and hold UP and DOWN
until the motor jogs

3.



2 sec.



Press and hold MY and DOWN
until the motor jogs

Test that the blind is now working
as expected